





11.02.20, 11:44

- General
- Network**
- Display
- Web App
- Login
- Systemstatus
- Support & License
- Logout
- Reboot
- Shutdown

### Network Settings

Ethernet adapter: eth0  Cable plugged checked: cable plugged in  
unchecked: cable unplugged

MAC Address: 18:9b:a5:c0:00:55  DHCP checked: dynamic  
unchecked: static

**IP4 Address** eth0 192.168.178.81 ^

IP4	IP4	IP4	IP4
192	168	178	81

**Netmask** eth0 255.255.0.0/16 ^

Netmask/CIDR: 255.255.0.0/16

**Gateway** eth0 192.168.178.1 ^

Gateway	Gateway	Gateway	Gateway
192	168	178	1

Set Gateway?

**DNS** eth0 DNS not set ^

DNS	DNS	DNS	DNS

Set DNS?

← Ping test the connection Reset Refresh Save

11.02.20, 11:42

- General
- Network
- Display**
- Web App
- Login
- Systemstatus
- Support & License
- Logout
- Reboot
- Shutdown

### Backlight

Brightnesslevel: 7 brightness: 1 - low to 7 - high

### Backlight dimming

Locking time: Off activate screen saver

Blanking time: Off switch off backlight

Restore Apply

### Rotation

Rotationangle: 0° rotate the display

Restore Apply

11.02.20, 11:42

- General
- Network
- Display
- Web App
- Login
- Systemstatus
- Support & License
- Logout
- Reboot
- Shutdown

### Webapp Settings

**Start Delay**  
 Delay in seconds: 10s configure the countdown  
-> startpage will be opened

**Check Http(s) Header**  
 Enable Http(s) Header Request checked: webapp can only be opened if URL is available  
unchecked: webapp can always be opened

**Browser Settings**  
 Enable Maximum Scale if the startpage is scaled incorrectly  
check the boxes  
 Enable Initial Scale

**Start URL**  
 Protocol: local configure startpage  
 Start URL: index.html

---

**Certificates**  
 Directories: if the website requires special certificates,  
these can be added

11.02.20, 11:42

- General
- Network
- Display
- Web App
- Login
- Systemstatus
- Support & License
- Logout
- Reboot
- Shutdown

### Password

**Change Password for Webconfiguration**

set password:  
between 6 and 16  
characters without space

default password:  
christ

Show Password?

back to Login

reboot system

shutdown system

⚙️  
11.02.20, 11:11

- ☐ General
- 🌐 Network
- 📺 Display
- 🗄️ Web App
- 👤 Login
- 📊 Systemstatus
- 📄 Support & License
- 🔒 Logout
- 🔄 Reboot
- 🔴 Shutdown

### Systemperformance

CPU Load is 11 %

RAM Load is 39 %

CPU Temperature is 52°

Uptime is 0d 1h 49min 8s

---

### USB and Storage Information

🔌 USB	Detected 3 device(s) ▼
💾 Storage	Detected 5 device(s) ▼

⚙️  
11.02.20, 11:38

- ☐ General
- 🌐 Network
- 📺 Display
- 🗄️ Web App
- 👤 Login
- 📊 Systemstatus
- 📄 Support & License
- 🔒 Logout
- 🔄 Reboot
- 🔴 Shutdown



---

#### Device Support

**Linux Support**  
 Christ - Electronic Systems GmbH  
 Alpenstraße 34  
 D-87700 Memmingen  
 Tel. +49 (0)8331/8371-798  
 E-Mail: linux@christ-es.de

---

#### Disclaimer

Technical data are subject to modification and delivery subject to availability. Any liability that the data and illustrations are complete, actual or correct is excluded. Designations may be trademarks and/or copyrights of the respective manufacturer; the use of which by third parties for their own purposes may infringe the rights of such owner.

---

## From ideas to reality

**Christ Electronic Systems GmbH**  
 Manufacturer of industrial electronics

**Contact information:**  
 Christ Electronic Systems GmbH  
 Alpenstraße 34  
 87700 Memmingen  
 Germany  
 Phone: +49 8331 8371 0  
 E-Mail: info@christ-es.com  
 www.christ-es.com

We are a German developer and manufacturer of innovative HMI-systems for demanding industrial applications. Christ offers an extensive range of:

TOUCH PANEL PCs	x86 and ARM
TOUCH MONITORS	7" to 24"
SINGLE BOARD COMPUTER	Windows and Linux
VISUALISATION SYSTEMS	HMI and SCADA



---

#### License

WebConfig license information

**The MIT License**  
 Copyright (c) 2017-2020 Christ Electronic Systems GmbH

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.